



Zebco 33 The Spool and the Line Replacement

In this guide you will be able to take apart the Zebco 33, remove the old line from the spool, and replace it with new line.

Written By: Renecee





TOOLS:

- [Utility Scissors](#) (1)
- [Utility Knife](#) (1)



PARTS:

- [Monofilament fishing line](#) (1)

Step 1 — The Spool and the Line



- Remove the old line remaining on the Zebco 33 by pressing down on the large spool release button on the back of the reel. Pull the old line off the reel.

Step 2



- Open the front spool cover of the Zebco 33 reel by turning it to the left and pulling it straight off.

Step 3



- Cut the line free from the Zebco 33 spool. Pull the line through the front spool cover and then through the line.

Step 4



- Thread the line through the hole in the center of the front spool cover and then around the spool of the reel.

Step 5



- Attach the line to the spool of the Zebco 33 with a knot. Double the knot and then pull the knot down tightly against the spool of the reel. Clip the extra line from the knot.

Step 6



- Put the front spool cover back on the reel. Hold the line a few inches in front of the spool and apply slight tension to the line. Wind the line onto the reel by turning the handle of the reel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-26 04:56:13 PM.